

EZbasket™ Installation Instructions

Step 1

Measure and mark (notch or nail) the saw-cut location on the forms.

Step 2

Pull string lines then spray paint saw-cut locations on the subgrade.

Step 3

Lay out one row of baskets over painted marks on the subgrade. Keep plates a minimum of 12” away from the intersection of two joints.

Step 4

Place concrete ensuring that baskets maintain alignment over painted marks.

Step 5

Screed and finish concrete as normal.

Step 6

Using notches or nails on forms, snap chalk lines to mark location of saw-cut.

Step 7

Saw-cut joints along chalked lines to the specified depth.
