



Installation Instructions

Step One: Placement

After all slab prep work has been completed, and the slab (flooring) is cured and dry, unroll the desired amount of EZcover™ floor covering and place where needed. Install the cover “soft” side down and “hard” side up.

Step Two: Cutting and Shaping

If necessary, cut the EZcover™ pad with heavy duty serrated shears to conform to angles and edges.

Step Three: Tape Edges

Place rolled out sections of EZcover™ side-by-side and abutted at the edges. To avoid trip and fall hazards, properly tape down the abutted sections (all edges and corners) with an owner approved non residue industrial grade adhesive tape. Avoid edges and ends which may curl if not taped properly.

Step Four: Repair

If any section of the protective covering becomes ripped, torn, excessively soiled or damaged, cut away the undesired area, and replace it with a new section of EZcover™, then tape down the new seam.

Step Five: Reuse

If reusing or moving a section of EZcover™ from one area of the slab (flooring) to another, carefully inspect the used portion prior to second use to avoid spreading contaminants from one area to another.

Step Six: Disposal

Because EZcover™ is a cellulose based product, it is biodegradable and landfill friendly. Simply discard used sections of the covering along with other typical construction debris.

Precautions:

- *Keep away from fire and flame.
- *Product is designed for indoor usage, store in a cool dry place.
- *Always use proper PPE (personal protective equipment) when working with the EZcover™ blanket.
- *Although EZcover™ is designed to help protect flooring from typical spills and impacts, care should always be used when working in/around completed flooring to avoid potential damages.
- *No warranties implied or otherwise are given for the usage of this product.

For additional information contact: McTech Group, Inc. 770-913-8363 / 1-866-913-8363